

How To Assemble Your AMPS Adapter

Assemble your iPad cradle per the instructions included from National Products (Ram-Mount). Attach the iPad cradle to the AMPS Adapter using (4) machine screws and (4) nylon insert nuts. Tighten the nylon insert nuts.

NOTE: 7/32" and 2mm Allen wrenches are included for assembly/disassembly. Keep these in a safe place.

TOOLS REQUIRED:

1. Phillips screwdriver
2. Pliers or adjustable wrench
3. 7/32" Allen wrench (included)



IMPORTANT: If you wish to disassemble your SnakeClamp, loosen the set screw using the included 2mm Allen Wrench PRIOR to removing the 3/8" screw.

When reassembling your SnakeClamp, tighten the 3/8" screw so that the spring washer is about half compressed. Then gently tighten the set screw.

SnakeClamp Products

www.SnakeClamp.com support@snakeclamp.com

