

How To Assemble Your Magnet Base

TOOLS REQUIRED:
7/32" Allen wrench (included)

Attach the gooseneck arm to the base using the short 3/8" screw.
Insert lock washer and washers as shown. Use allen wrench to tighten.



SnakeClamp Products

www.SnakeClamp.com support@snakeclamp.com

