

How To Assemble Your Multiclamp

TOOLS REQUIRED:

7/32" Allen wrench (included)
2mm Allen wrench (included)

Insert lock washer and flat washer as shown. Loosen set screw at end of gooseneck arm. Thread gooseneck onto 3/8" stud and tighten by hand. Gently tighten set screw.

NOTE: Prior to threading the 3/8" stud into the gooseneck, you must first loosen the 4mm set screw. Then GENTLY tighten the set screw.



SnakeClamp Products

www.SnakeClamp.com support@snakeclamp.com

snakeclamp