

How To Assemble Your Round Base

Loosen the 4mm set screw on the end of the gooseneck. Then attach the gooseneck arm to the round base using one 3/8" round-head screw. Insert lock washer and flat washer as shown. GENTLY tighten the 4mm set screw.

TOOLS REQUIRED: 2 mm and 7/32" Allen wrench (included)

WARNING: Prior to inserting the 3/8" screw, you must first loosen the 4mm set screw. After tightening the 3/8" screw, GENTLY tighten the set screw.



- SnakeClamp Products -

www.SnakeClamp.com

support@snakeclamp.com

snakeclamp