

Assembly Instructions for Table Clamp

Loosen set screw at end of gooseneck using the 2mm Allen wrench. Attach the gooseneck arm to the table clamp using one 3/8" flat-head screw. Insert lock washer and washer as shown. Gently tighten the 4mm set screw.

TOOLS REQUIRED: 2 mm and 7/32" Allen wrench (included)



WARNING: Prior to inserting the 3/8" screw, you must first loosen the 4mm set screw. After tightening the 3/8" screw, GENTLY tighten the set screw.

SnakeClamp Products LLC

www.SnakeClamp.com support@snakeclamp.com

snakeclamp