

Assembly Instructions for Table Clamp

Loosen set screw at end of gooseneck using the 2mm Allen wrench. Attach the gooseneck arm to the table clamp using one 3/8" flat-head screw. Insert lock washer and washer as shown. GENTLY tighten the 4mm set screw.

TOOLS REQUIRED: 2 mm and 7/32" Allen wrench (included)



SnakeClamp Products LLC

www.SnakeClamp.com

support@snakeclamp.com

snakeclamp